


1 Find Measurements

$$\boxed{} + \boxed{} + \boxed{} = \boxed{}$$

A B C D



2 Determine Support Size

Referencing measurements A & B from step-1, choose a support bracket (1", 1-1/4", or 2") that will provide enough clearance.

Left Support:


X	Model	Width
<input type="checkbox"/>	T-500	1"
<input type="checkbox"/>	T-502	1-1/4"
<input type="checkbox"/>	T-503	2"

Right Support:

X	Model	Width
<input type="checkbox"/>	T-500	1"
<input type="checkbox"/>	T-502	1-1/4"
<input type="checkbox"/>	T-503	2"

$$\boxed{} + \boxed{} = \boxed{}$$

Left support width Right support width E



3 Tray/Drawer Box Width

$$\boxed{} - \boxed{} - \boxed{} = \boxed{}$$

D E SR Box Width

SLIDE TYPE	SLIDE REDUCTION
Side-Mount*	
Double Captive Epoxy	1-1/16"
Full Extension Ball Bearing Side Mount	1-1/16"
Blum Undermount	
1/2" Drawer Box Side	5/8"
5/8" Drawer Box Side	3/8"

*Slide Reduction is always 1-1/16" for side-mount slides, regardless of box side thickness.



The Cabinet Guy & QuikDrawers.com